



When you insert the corners in to the base, make sure the top flat surfaces are facing the right way

